

RADAR GUN SET-UP INSTRUCTIONS



1. Gun must be plugged into outlet or have 2 new 9V batteries. Batteries only last about 2 hours so it is best if the gun is plugged into an outlet.
2. Mount gun on tripod about 2 feet off ground
3. Set the tripod about 2 feet behind the back of the cage (behind back-stop canvas, outside of the net) make sure the gun is centered between the poles (do not WORRY the gun will read through the back-stop canvas and netting).
4. Aim gun directly towards person pitching with the gun pointed slightly upward.
5. Connect cable from gun to LCD display. Turn gun ON to cont. and have fun!