

# Events By Eagle

1327 North Reading Road ~ Stevens ~ PA ~ 17578  
Phone: 717.336.0777 ~ Fax: 717.336.0975

## Sno-Kone Machine



### **OPERATING INSTRUCTIONS:**

Start the motor and fill the gooseneck with ice cubes 3” – 4” in side. Fill to about an inch or so from the top, the larger the pieces of ice the better the snow. Push the handle down to press the ice against the cutter head. A firm even pressure is all that is required. It is better to relieve the pressure two or three times on the way down, this lets the ice rearrange itself and get a bite. Do not force the handle too much, as it could result in the motor stalling. When more pressure is necessary, relieve the handle and come down again. **DO NOT PUT YOUR HAND IN TO TRY AND LOOSEN THE ICE.** Too much pressure makes the ice come out course. Too little pressure makes the ice mushy. In normal operations the motor gets warm. A surface temperature of 150 degrees is normal.

### **WARNING:**

NEVER PUT YOUR FINGERS OR ANY OBJECT OTHER THAN ICE INTO THE SHAVER WHILE THE MOTOR IS RUNNING. YOU BE SERIOUSLY HURT IF YOU DISOBEY THESE INSTRUCTIONS. WE DO NOT ASSUME ANY LIABILITY FOR INJURY DUE TO CARELESS HANDLING OF EQUIPMENT. ALWAYS UNPLUG MACHINE BEFORE CLEANING AND SERVICING.

### **CLEAN UP:**

Clean with hot soapy water before returning. If returned unclean, a cleaning charge will apply.

### **RETURN:**

**ALL PART OF THE MACHINE INCLUDING PUMPS AND JUGS, IF ANYTHING IS MISSING YOU WILL BE CHARGED.**